



## LIGHT COLUMN ARCUATO



## User's manual for Light column Arcuato

Congratulations to the purchase of your Light column Arcuato providing great dispersion of light and quick&easy snapframe technique for simple exchange of your posters or any other designs.

Light column Arcuato are of EU preferential origin.

Light column Arcuato frame consists of serie of silver anodized profiles and accessories designated for manufacturing high quality lightboxes for indoor use. These lightboxes are offered in both single and double-side version.

Drill holes on the backside of the frame allow easy wall-mounting. Two ceiling hooks are also available for hanging up lightboxes - these do not come standardly with Light column Arcuato and need to be ordered separately; they are supplied standardly only with double-sided version of lightboxes. Light column Arcuato are certified in accordance with CE regulations.

Please follow instructions for a sale and proper use:

- Light column Arcuato is for indoor use only
- No liquid or moisture is allowed inside Light column Arcuato in connection with high voltage
- Take off the electric power before opening / service of the lightbox by pulling the plug out off the socket
- Profiles are sharp, please be careful when touching the corners
- Do not place Light column Arcuato on flammable surface
- Contact your supplier with any questions or doubts

Changing light tubes (following steps can do only trained person):

- Disconnet device from electric power by pulling the plug out of the socket
- Put down Light column Arcuato on a stable surface
- Open the snap profiles (A) and remove the protection foil with poster
- Carefully push back (B) and put out the plexi opal from the profile channel (C)
- Release the light tube by moving round and sidelong-releasing from electronic bases (D)
- Replace the light tube and follow the above instruction in reverse order
- Close the snap profiles, put the Light column Arcuato back on its place and put the plug back in the socket

Type of light tubes to be used:

Product specification:

Light column Arcuato single and double-sided (art. code TL)

Power consumption:	A1	1 x 58 W
	70x100	2 x 36 + 16 W